



1(800) FloBeds.com  
www.FloBeds.com  
The First Personally Engineered Mattress

## ATTACHING HEADBOARD BRACKETS TO YOUR FOUNDATION

1. Turn foundation upside down. Place Headboard Brackets on head outside corners end of foundation with triangle side of bracket facing out.
2. Using a power screwdriver, install the headboard brackets with the supplied screws directly into the foundation bottom.
3. Turn the foundation over.
4. To complete the installation, simply bolt the headboard onto the bracket. Most headboards come with the long bolt needed to attach it to the bracket; this long bolt is not included with the headboard brackets. For extra bracket strength, use the included washer to go between the bracket and bolt or nut.

